



urbanmac

GARDEN BOXES FOR CITY FOLK

Hints and Tips to Assemble your Compost Bin Double or Triple

GET IN TOUCH

PHONE
09 236 3727

EMAIL
sales@urbanmac.co.nz

WEB
www.urbanmac.co.nz

Your kitset will contain:

- 2 ends pre-assembled and 1 pre-assembled centre (flat one end)
- 6 long rails.
- 10 short rails with lugs. 2 rails without lugs.
- 24 x 75mm Stainless Steel Square Drive self-tapping wood screws.
-

1. You'll need a "square drive" screwdriver bit and power drill. (You can do it without a power drill and just a hand screwdriver but then you would also need a gorilla because humans just aren't strong enough to do it alone).
2. Set it up where you want to leave it and make sure that you can either walk around it or reach all four corners. Otherwise you will end up with parts of your compost bin that you can't use.
3. You might notice that we haven't made holes in the lengths of timber which you screw into. We did that on purpose to help the screw take a better grip.
4. You will need to push on the screws reasonably hard as they go in and be careful not to round off the part on the screw where the screwdriver fits. If that happens and the screw is only halfway in, well - you're screwed!
5. The screw tops need to go at least halfway into the post. We have drilled the holes big enough for the screw head to fit into.
6. Separate the side frames received which are pre-assembled.
7. Separate the loose boards (front boards have the lugs attached)
8. Attach plain long boards at the back and front, matching the gaps to the side rails. (find it easiest if you attach the bottom board first then slide the rest in to get a tight fit.)
9. Place centre divide, screw to back boards and attach the front bottom rails. (attach either 1 or 2 bottom boards)
10. Drop boards with spacers attached into front.

13. Fill it up!

If you have any problems - give us a call, we might be able to help guide you over the phone.